

WHEN UNPACKING KEEP REPACKING IN MIND

INSTALLATION INSTRUCTIONS:

1. TAKE THE DISK PLAYERS OUT OF THE BOX AND CONNECT THEM TO THE POWER STRIP
2. TAKE THE GLASS DISKS AND PLACE THEM CAREFULLY ON THE TRAYS. 1 TO 1, 2 TO 2, ETC
3. CONNECT THE SYNCHRONIZER TO THE POWER STRIP AND CONNECT THE FOUR OUTLETS TO THE "RS232" JACK ON THE PLAYERS IN ANY ORDER.
4. CONNECT THE FOUR VIDEO AND FOUR AUDIO CABLES TO THE FOUR MONITORS IN THE FOLLOWING WAY:

1	2
4	3

 (OR USE ANTENNA CABLES)
5. START THE INSTALLATION BY TURNING THE POWER STRIP OFF AND BACK ON. THE 3 GREEN INDICATOR LIGHTS ON THE PLAYERS WILL START BLINKING ONE BY ONE, SHOWING BLUE SCREEN ON THE MONITORS UNTIL ALL FOUR PLAYERS HAVE FOUND THE IN-POINT. THE INSTALLATION PLAYS CONTINUOUSLY UNTIL TURNED OFF (USE POWER STRIP).
6. TUNING MONITORS AND SOUND:
TURN CONTRAST $\frac{3}{4}$ UP, AND BLACK $\frac{3}{4}$ DOWN (FROM $\frac{1}{2}$ POSITION). TRY TO MATCH THE FOUR MONITORS THE BEST YOU CAN. TUNE THE SOUND VOLUME TO THE SECOND SEGMENT (THE TRAIN CONDUCTORS).

FOR ANY ADDITIONAL INFORMATION, CALL ME 505-424-8786 OR

E-MAIL: WOODYV@SANTAFE.EDU. BEST, STEINA

BREAKING DOWN THE INSTALLATION:

BE SURE TO REMOVE THE DISK
BEFORE DISCONNECTING POWER

PACK THE PLAYERS IN PLASTIC BAGS
BEFORE PLACING THEM INTO THE
BOXES

Thanks, Sevin!

I look forward to
seeing more work by
you!

on the best,

June

IN THIS BOX:

- 4 SYNCHRONIZER CABLES RS 232
- 4 AUDIO CABLES RCA - RCA
- 4 VIDEO CABLES RCA - RCA
- 1 A.C. STRIP
- 1 REMOTE CONTROL
- 1 AC. CABLE FOR SYNC.
- 4 LASER DISKS IN A SHATTER-
PROOF BOX